SAMSUNG

Model : SR-28/29
SR-32/33

CFC FREE
GREEN

SERVICE Manual

REFRIGERATOR



SR-28/29
SR-32/33

CONTENTS

1. Safety Precautions and warnings
2. Product specifications
3. Electrical part specifications & standard
4. Product dimension
5. Identifying and disassembling the parts
6. Schematic diagram of coolant gas circulation
7. Circuit diagram
8. Packing dimension
9. Schematic diagram of cold air flow
10. Troubleshooting method
11. Exploded view & part list
12. How to disassemble of freezing compartment
13. How to disassemble of refrigerating compartment

1. Safety precautions and warnings

Read all instructions before using this appliance in order to avoid risk of accident or possible damage.

Warning/Caution

Warning	This symbol is intended to alert the user to the possible death or injury.
Caution	This symbol is intended to alert the user to the possible injury or damage.

Description of symbols

	Indicates prohibition
	Do not disassemble
	Do not contact
	Adhere the instruction strictly
	Unplug from the electrical outlet
	Earth the appliance to avoid the risk of an electric shock

Warning

Do not plug multiple electrical appliances into the same outlet.
- This may cause abnormal heating or a fire hazard.



Do not attempt to make repairs yourself.
- This could lead to fire hazard or abnormal operation causing severe personal injury.



Make sure the power cord is not crushed or damaged.
- Repair immediately all power cords or outlets that have become frayed or otherwise damaged.



Check the operating environment.
- Do not install the refrigerator in a humid (with condensation) location or on an unstable surface.



Do not attempt to make repairs yourself.
- This could lead to fire hazard or abnormal operation causing severe personal injury.



Make sure the power cord is not crushed or damaged.
- Repair immediately all power cords or outlets that have become frayed or otherwise damaged.



Caution

Do not store bottled food or drinks in the freezing compartment.

- Bottles may explode causing personal injury.

Prohibition

Do not store food in an unstable manner.

- Opening the door may trigger loose items to slip and cause injury.

Prohibition



Do not store anything other than food in the refrigerator.

- Medical supplies which need to be under strict temperature control should not be stored in the refrigerator.

Prohibition

Do not put anything on top of the refrigerator.

- Opening or closing the door may trigger loose items to slip and cause injury.

Prohibition

When replacing electric components, be sure to use rated components.

- Check the model, rated voltage, rated current, operating temperature etc. of the component.



When servicing the refrigerator, completely remove dust or foreign substances from the housing, electric connections and etc.

- This can protect against the risk of fire hazard caused by tracking and short circuit.

When servicing the refrigerator, completely remove dust or foreign substances from the housing, electric connections and etc.

- This can protect against the risk of fire hazard caused by tracking and short circuit.



After servicing the refrigerator, be sure to check the components are reassembled in a correct manner.

- The serviced unit should be reassembled and returned to its original assembly state.



Check the electrical parts for the trace of moisture penetration.

- When the trace of moisture penetration is detected, replace the part or try insulation tapping.



3. Electrical part specifications & standard

[CFC-FREE]

ITEM			STANDARD			
Model			SR-28/29		SR-32/33	
Power source			115V/60Hz	127V/60Hz	220V/50,60Hz	240V/50Hz
Refrigeration Cycle	Compressor	Model	SD152C-L1W2	SD152P-L1W2	SD152H-L1U2	SD162Q-L1U2
		Starting type	C.S.R		R.S.C.R	
		Oil charge	FREOL ∂–15c / 200cc			
	Evaporator		Split fin type			
	Condenser		Forced & natural convection			
	Dryer		Molecular sieve			
	Capillary tube		I.D 0.75 x L3400 (mm)			
Electrical	Thermostat	Freezer	PFN – C174S–03C			
		Refrigerator	D–705–E8			
	Defrost-thermo	Bimetal (OFF/ON)	Type	AC 250V / 5A		
			Oper. temp.	ON : –5 ±3˚C / OFF : 12±3˚C		
		Thermal fuse	Regularity	AC 250V / 10A		
			Oper. temp.	72±4˚C		
	Defrost-timer	Type	TMDE714F1	TMDE714A1		
		Cycle	6hr 35min			
		Time	13min 40s			
	Starting-relay	Model	912 x 32E100MQ16APE3		912 x 35E330MT16APE2	
		Resistance	10Ω±20%		33Ω±20%	
	Overload protector	Model	4TM427 PHBYY-53	4TM317 RHBYY-53	4TM265 RHBYY-53	4TM222 PHBYY-53
		Close temp.	69±9˚C			
		Open temp.	125±5˚C	130±5˚C	125±5˚C	
	Capacitor	Running	250VAC/8μF		350VAC/3.5μF	
		Starting	125VAC/100μF		–	
	Motor-geared		M2BC18AR02		M2LC18AR02	
	Heater-defrost		130W/93Ω	130W/124Ω	130W/372Ω	130W/443Ω
	Lamp		110V/15W	127V/15W	220V/15W	240V/15W
	Door-Switch		125/250V/0.5A 1.4/0.7A			
	Earth screw		BSBN(Brass screw)			

2. Product Specifications

ITEM		STANDARD	
Model name		SR-28/29	SR-32/33
Type		2-Door Freezer/Refrigerator	
Power source		AC 115V/60Hz, 127V/60Hz, 220V/50~60Hz, 230~240V/50Hz	
Net capacity (*l*/cu.ft)	Freezer	70(2.5)	70(2.5)
	Refrigerator	162(5.7)	195(6.9)
	Total	232(8.2)	265(9.4)
Net dimension (*mm*)	Width	578	
	Depth	610	
	Height	1544	1669
Net weight (kg)		52	57
Refrigerant		R-134a(130gr)	
Temperature control		Dial(Thermostat)	
Defrosting		Automatic(Start-Finish by Timer)	
Foam insulation	Cabinet	Cyclo-pentane	
	Door	Cyclo-pentane	
Liner / Door panel		ABS(SD-0150)	
Accessory parts	Door storage	3 Guard-freezer 1 Guard-egg 1 Guard-variety 1 Guard-jumbo	
	Inside storage	1 Base-tray ice 1 Case-tray ice, assy 1 Tray-ice cube 1 Shelf-freezer 1 Tray-chilled room(H,M,G) 1 Cover-chilled room(H,M,G) 1 Tray-vegetables 1 Cover-vegetable 2 Shelf-refrigerator 1 Shelf-chilled (L,) 1 Shelf-chilled ,wire(N) 1 Shelf-ref wire (L,G, N) 2 Shelf-ref wire (G, N)	
	Interior lamp(H/M)	2 (Refrigerator) / 1 (Refrigerator)	
	Movable caster	2 (Rear)	
	Angle adjustment	2 Legs (Front)	

4. Product Dimension



MODEL	A	B	Remark
SR-32/33	1669	1049	
SR-28/29	1544	924	

5. Identifying and disassembling the parts



To remove shelves in the freezing compartment

- Frist remove the icemaking molds. Tilt the shell up at front, then lift it up pull it out of the tracks.



To remove bio deodorizer

- While pushing the front end knob of the bio deodorizer, pull it downward to disengage.



To remove shelves in the refrigerating compartment

- Hold the shelf by the front and pull it forward of the rack.



To remove shelves in the chilled compartment

- Lift up the cover, push the cover to the right (as shown) until the mounting hook(1) disengages, then disengage the other mounting hook (2) and pull out the cover.
- Pull the shelf forward until it stops. then lift it up and pull it out.

Disassemble





- With shelf front raised slightly, engage, the roller between the rails and slide it back.
- To repace the cover, first engage the mounting hook (1) as shown, then engage the other hook (2) and push in.

Reassemble



To remove door bins

- While pushing the bin to the left, lift it up to disengage.



To remove storage drawers and covers

- Lift up to remove the cover. Pull the drawer helf way out, then lifting it up, pull it out completely.



6. Schematic diagram of coolant gas circulation

COMPRESSOR --> CLUSTER PIPE --> HOT PIPE --> DRYER --> CAPILLARY TUBE
--> EVAPORATOR --> ACCUMULATOR --> SUCTION PIPE --> COMPRESSOR



7. Circuit diagram

7-1 [220V/50, 60Hz, 230~240V/50Hz] SR-28/29, SR-32/33

(SR-32/33, SR-28/29 (H-OPTION)



(SR-32/33, SR-28/29 (H-OPTION)



GRY – GRAY
PNK – PINK
BRN – BROWN
WHT – WHITE
YEL – YELLOW
RED – RED
S/BLU – SKY BLUE
BLU – BLUE
BLK – BLACK
W/BLK – WHITE/BLACK
ORG – ORANGE
PRP – PURPLE

7-2 [110V/ 60Hz, 115V/60Hz, 127V/60Hz] SR-28/29, SR-32/33

(SR-32/33, SR-28/29 (H-OPTION)



(SR-32/33, SR-28/29 (H-OPTION)



GRY – GRAY
PNK – PINK
BRN – BROWN
WHT – WHITE
YEL – YELLOW
RED – RED
S/BLU – SKY BLUE
BLU – BLUE
BLK – BLACK
W/BLK – WHITE/BLACK
ORG – ORANGE
PRP – PURPLE

10. Troubleshooting method

10-1 The refrigerator does not operate



10-2 Defrosting mechanism does not work



10-3 Defrosting mechanism does not work


Does the cooling fan operate?
No
• Check the cooling fan motor
• Check the door switch
Yes
Is the freezer defrosted normally?
No
• Defrost timer
• Temperature fuse/Bimetal thermometer
• Defrost heater
Yes
Is the door closed properly?
No
• Check that the door gasket is properly seled, check for the damaged gasket.
Yes
Is the door stopper hinge normal?
No
• Correct or readjust the door stopper hinge
Yes
Is too much food stored in the freezer compartment?
No
• Tightly cover stored ice cubes.
• Tightly cover stored frozen food.
• Destribute food evenly in the comparment.

10-4 Trouble check for the cooling cycle


Symptom
Cause
Suggestions
• The EVAP cools down and warms again.
• The condenser warms in proportion as the EVAP cools.
• The process continues to repeat.
Moisture in the refrigerant causes the malfunction.
Replace the refrigerant
• The condenser is cold.
• The EVAP is not cold.
• The temperature of the compressor is high.
Foreign substances hamper the cooling cycle.
Locate the disturbed section and make repairs
• No difference in temperatures between suction pipe and discharge pipe.
• The temperature of the compressor is maintained at room temperature.
• The EVAP does not cool down.
The compressor is defective
Replace the compressor
• Frost on the suction pipe.
• The condenser is overheated.
• The refrigeration in the EVAP is not effecient.
Too much refrigerant
Replace the refrigerant
• The condenser is cold.
• The compressor surface temperature is high.
• The refrigerator is not easily get cooled.
Refrigerant leaks.
(Slight refrigerant leakage causes partial cooling with frost on the EVAP)
After welding the leaked spot, replace the refrigerant

10-5 Diagnosing the main components

<table>
<tr><th>Components</th><th>Diagnosing methods and criteria</th><th>Location</th></tr>
<tr><td>Compressor</td><td>• Use the tester to measure the resistance.
– Bring the component to cool down completely before measuring.
<table>
<tr><th>Measuring point</th><th>Normal</th><th>Abnormal</th></tr>
<tr><td>Primary iwre</td><td>Approx 10 ~</td><td rowspan="2">0Ω and ∞Ω</td></tr>
<tr><td>Secondary wire</td><td>500kΩ</td></tr>
</table></td><td>Mechanical compartment</td></tr>
<tr><td>P.T.C Relay</td><td>• Use the tester to measure the resistance.
– Bring the component to cool down completely before measuring.
<table>
<tr><th>Normal</th><th>Abnormal</th></tr>
<tr><td>Approx ∞Ω ~ kΩ</td><td>0Ω and ∞Ω</td></tr>
</table></td><td>Mechanical compartment</td></tr>
<tr><td>Condenser</td><td>• Use the tester to measure the resistance.
– Bring the component to cool down completely before measuring.
<table>
<tr><th>Normal</th><th>Abnormal</th></tr>
<tr><td>Approx 10Ω ~ 80kΩ</td><td>0Ω and ∞Ω</td></tr>
</table></td><td>Electrical equipment box</td></tr>
<tr><td>Overload relay</td><td>• Use the tester to measure the resistance.
<table>
<tr><th>Normal</th><th>Abnormal</th></tr>
<tr><td>Approx 200kΩ</td><td>0Ω and ∞Ω</td></tr>
</table></td><td>Mechanical compartment</td></tr>
<tr><td>Circuit-motor
&
Fan-motor</td><td>• Use the tester to measure the resistance.
– Bring the component to cool down completely before measuring.
<table>
<tr><th>Normal</th><th>Abnormal</th></tr>
<tr><td>Approx 100Ω ~ 20kΩ</td><td>0Ω and ∞Ω</td></tr>
</table></td><td>Mechanical compartment
Freezing compartment</td></tr>
<tr><td>Rotating blade geared-motor</td><td>• Use the tester to measure the resistance.
– Bring the component to cool down completely before measuring.
<table>
<tr><th>Normal</th><th>Abnormal</th></tr>
<tr><td>Approx 10Ω ~ 20kΩ</td><td>0Ω and ∞Ω</td></tr>
</table></td><td>Refrigerating compartment</td></tr>
<tr><td>Door switch</td><td>• Use the tester to measure the resistance.
<table>
<tr><th>Measuring point</th><th>Normal</th><th>Abnormal</th></tr>
<tr><td>A B contact point</td><td rowspan="2">Approx 200MΩ</td><td rowspan="2">∞MΩ and ∞Ω</td></tr>
<tr><td>When the switch is on by the contact</td></tr>
</table></td><td>Between the upper and the lower doors</td></tr>
<tr><td>Defrost timer</td><td>• Use the tester to measure the resistance.
<table>
<tr><th>Measuring point</th><th>Normal</th><th>Abnormal</th></tr>
<tr><td>Between terminals</td><td>Approx 200KΩ</td><td rowspan="2">0Ω and ∞Ω</td></tr>
<tr><td>Temperature fuse terminal</td><td>Approx 10Ω~300KΩ</td></tr>
</table></td><td>Electrical equipment box</td></tr>
<tr><td>Defrost heater</td><td>• Use the tester to measure the resistance.
– Bring the component to cool down completely before measuring.
<table>
<tr><th>Normal</th><th>Abnormal</th></tr>
<tr><td>Approx 3KΩ ~ 6KΩ</td><td>∞ MΩ ~ ∞Ω</td></tr>
</table></td><td>Lower EVAP</td></tr>
<tr><td>Bimetal Temperature fuse</td><td>• Use the tester to measure the resistance.
<table>
<tr><th>Measuring point</th><th>Normal</th><th>Abnormal</th></tr>
<tr><td>Bimetal terminal</td><td rowspan="2">Approx 200MΩ</td><td rowspan="2">∞Ω ~ ∞Ω</td></tr>
<tr><td>Temperature fuse terminal</td></tr>
</table></td><td>EVAP</td></tr>
</table>

11. Exploded View & Parts List

11-1 Freezing compartment



NO	CODE-NO	DESCRIPTION	SPECIFICATION	SR-32/33					SR-28/29				
				H	M	L	N	G	H	M	L	N	G
1	DA61-70003A	SUPT-TARY,ICE	HIPS	1	1	1	1	1	1	1	1	1	1
2	DA67-40180A	TRAY-ICE(A)	P.P	2	2	2	2	2	2	2	2	2	2
3	DA67-10252B	CASE-TRAY, ICE	HIPS	1	1	1	1	1	1	1	1	1	1
4	DA67-10210C	TRAY-ICE, CUBE	GPPS	1	1	1	1	1	1	1	1	1	1
5	DA61-20119A	SPRING-ICE	PI1.0 L162.6	2	2	2	2	2	2	2	2	2	2
6	DA67-20167A	SHELF-FRE	GPPS	1	1	1	0	0	1	1	0	0	0
7	DA71-20252A	FIXER-GROMMET D/FRE	ABS	3	3	3	3	3	3	3	3	3	3
8	3523-202-340	SWITCH-DOOR	NY 694 VO	1	1	1	1	1	1	1	1	1	1
9	DA67-30266D	CAP-SCREW	P,P	1	1	1	1	1	1	1	1	1	1
10	6002-000454	SCREW-TAP, TH	2-4 x 12 STS304	2	2	2	2	2	2	2	2	2	2
11	DA47-10107H	THERMOSTAT	PCC PFN174S	1	1	1	1	1	1	1	1	1	1
12	DA39-20124C	WIRE-LEAD, THERMO	-	1	1	1	1	1	1	1	1	1	1
13	DA63-10246S	COVER-EVAP, FR	P.P	1	1	1	1	1	1	1	1	1	1
14	DA63-10254A	COVER-EVAP, RE	ABS SCRAP	1	1	1	1	1	1	1	1	1	1
15	DA61-20128B	SPRING-FAN	STS 27	1	1	1	1	1	1	1	1	1	1
16	DA31-20002A	FAN	ABS	1	1	1	1	1	1	1	1	1	1
17	DA63-40119A	GROMMET-FAN, MOTOR	SILICON	2	2	2	2	2	2	2	2	2	2
18	DA36-10109S	MOTOR (220~240V)	IS3210-SNC7A	1	1	1	1	1	1	1	1	1	1
	DA31-10109V	" (110V~127V)	IS3210-SNP6A	1	1	1	1	1	1	1	1	1	1
19	DA63-10459A	COVER-FAN, MOTOR	P.P	1	1	1	1	1	1	1	1	1	1
20	6002-000454	SCREW-TAP, TH	1-4 x 12 FE, FZY	1	1	1	1	1	1	1	1	1	1
21	DA63-110001N	COVER-EVAP,ASSY(115V~127V)		1	1	1	1	1	1	1	1	1	1
	DA63-110001M	COVEREVAP,ASSY(220V~240V)											
22	6002-000213	SCREW-TAP,TH	2-4 x 12 STS304	2	2	2	2	2	2	2	2	2	2
23	DA59-40218A	EVAPORATOR	-	1	1	1	1	1	1	1	1	1	1
24	DA47-10103J	BIMETAL-THERMO	125, 250/50, 60-5/12	1	1	1	1	1	1	1	1	1	1
25	DA64-40126C	KNOB-F, THERMO	ABS	1	1	1	1	1	1	1	1	1	1
26	DA63-10389A	COVER-AIR	P.P	1	1	1	1	1	1	1	1	1	1
27	DA63-10488B	COVER-HEATER	A1050	1	1	1	1	1	1	1	1	1	1
28	DA47-20150K	HEATER-DEFROST	220V/130W	1	1	1	1	1	1	1	1	1	1
	DA47-20150H	"	240V/130W	1	1	1	1	1	1	1	1	1	1
	DA47-20150L	"	110V/130W	1	1	1	1	1	1	1	1	1	1
	DA47-20150N	"	127V/130W	1	1	1	1	1	1	1	1	1	1
29	6002-000454	SCREW-TAP,TH	2-4 x 12 STS304	3	3	3	3	3	3	3	3	3	3
30	DA64-20150M	TRIM-SHELF	RD-PVC	0	0	0	1	1	0	0	1	1	1
31	DA67-20168B	SHELF-FRE(WIRE)	MSWR10	0	0	0	1	1	0	0	1	1	1

Indicated part is for electrical safety components

11-2 Refrigerating compartment



NO	CODE-NO	DESCRIPTION	SPECIFICATION	SR-32/33					SR-28/29				
				H	M	L	N	G	H	M	L	N	G
1	DA72-40193B	SPACER-DAMPER, B	FOAM-PS	1	1	1	1	1	1	1	1	1	1
2	DA67-10246B	ASSY-THERMO, DAMPER	705-E9C	1	1	1	1	1	1	1	1	1	1
3	DA72-40235A	SPACER-DAMPER, A	FOAM-PS	1	0	0	0	0	1	0	0	0	0
3-1	DA72-40194B	SPACER-DAPMER, A	FOAM-PS	0	1	1	1	1	0	1	1	1	1
4	DA63-10260J	COVER-MULTI, REF(X)	P.P	1	0	0	0	0	1	0	0	0	0
5	DA47-40112L	SOCKET-LAMP	250V 1A	1	0	0	0	0	1	0	0	0	0
5-1	DA47-40114D	SOCKET-LAMP(B)	250V 1A	0	1	1	1	1	0	1	1	1	1
6	DA64-10147	KNOB-DAMPER, THERM**O**.	ABS	1	1	1	1	1	1	1	1	1	1
7	DA63-10395B	COVER-LAMP, REF	MIPS	1	0	0	0	0	1	0	0	0	0
8	DA74-30135A	HOSE-DRAIN, CONNECT	SILICON	1	1	1	1	1	1	1	1	1	1
9	DA47-30151B	ASSY-DAMPER	SR28/29(220~240V),32/33(240V)	1	0	0	0	0	0	0	0	0	0
	DA47-30151C	ASSY-DAMPER	SR-28/29(110~127V)	1	0	0	0	0	0	0	0	0	0
	DA4730151D	ASSY-DAMPER	SR32/33(220V)	0	0		0	0	1	0	0	0	0
	DA47-30151E	ASSY-DAMPER	SR-32/33(110~127V)	0	0	0	0	0	1	0	0	0	0
10	DA02-90108B	CATALYST-LTC	T5 W42 L42	1	1	0	0	0	0	0	0	0	0
11	DA63-10461B	CAP-PURIFIER	P.P	1	1	0	0	0	0	0	0	0	0
12	DA67-10443A	CASE-PURIFIER	P.P	1	1	0	0	0	1	1	0	0	0
13	4713-000188	ASSY-LAMP	220V~15W	2	1	1	1	1	2	1	1	1	1
	4713-001035	ASSY-LAMP	110V/30V/14W/16W	2	1	1	1	1	2	1	1	1	1
	DA63-000213	ASSY-LAMP	240V/15W	2	1	1	1	1	2	1	1	1	1
14	DA67-40137A	TRAY-CHILLED, ROOM	GPPS	1	1	0	0	1	1	1	0	0	1
15	DA63-10983B	COVER-CHILLED, ROOM	"	1	1	0	0	1	1	1	0	0	1
16	DA67-20164F	SHELF-REF(GOLD SP)	"	2	2	2	0	0	2	2	2	0	0
	DA67-20164F	SHELF-REF	"	2	2	2	1	0	2	2	2	0	0
17	DA63-10248C	COVER-VEGETABLE	"	1	1	1	1	1	1	1	1	1	1
18	DA67-10196A	TRAY-VEGETABLE	"	1	1	1	1	1	1	1	1	2	1
19	6002-000471	SCREW-TAP, TH	1-4 x 12 STS304	2	2	2	2	2	2	2	2	2	2
20	DA63-40134A	GROMMET-MOTOR	NBR	1	0	0	0	0	1	0	0	0	0
21	DA31-10107D	GEARED-MOTOR	M2LC18AR01(220~240V)	1	0	0	0	0	1	0	0	0	0
	DA31-10107E	"	M2BC18AR01(110~127V)	1	0	0	0	0	1	0	0	0	0
22	DA63-40131A	FIXER-CHILLED, ROOM	ABS	2	2	0	0	2	2	2	0	0	2
23	DA31-20108A	BLADE-DAMPER	ABS	1	0	0	0	0	1	0	0	0	0
24	DA67-20165R	SHELF-CHILLED	GPPS	0	0	1	0	0	0	0	1	0	0
25	DA64-20150N	TRIM-SHELF	RD-PVC	0	0	0	3	2	0	0	0	3	2
26	DA67-20022A	SHELF-REF(WIRE)	MSWR10	0	0	0	2	2	0	0	0	2	2
27	DA67-20023A	SHELF-CHILLED(WIRE)	"	0	0	0	1	0	0	0	0	1	0
28	DA47-30150D	ASSY-DAMPER (MULTY)	SR28/29,DEODO.É	0	1	1	0	0	0	0	0	0	0
	DA47-30150F	ASSY-DAMPER "	SR32/33,NON.DEODO.	0	0	0	1	1	0	0	0	0	0
	DA47-30150B	ASSY-DAMPER "	SR-28/29, DEODO.	0	0	0	0	0	0	1	1	0	0
	DA47-30150E	ASSY-DAMPER "	SR-32/33,NON.DEODO.	0	0	0	0	0	0	1	1	0	0
29	DA63-10249J	COVER-MULTI, REF(M)	P.P	0	1	1	1	1	0	1	1	1	1
30	DA63-10388A	COVER-LAMP, REF	MIPS	0	1	1	1	1	0	1	1	1	1

Indicated part is for electrical safety components

11-3 Door parts



NO	CODE-NO	DESCRIPTION	SPECIFICATION	SR-32/33					SR-28/29				
				H	M	L	N	G	H	M	L	N	G
1	DA91-10316A	ASSY-FOAM DOOR, FRE	SR-32/33 OPTION	1	1	1	1	1	0	0	0	0	0
1-1	DA91-10316B	"	SR-28/29 OPTION	0	0	0	0	0	1	1	1	1	1
2	DA91-10318A	ASSY-FOAM DOOR, REF	SR-32/33 OPTION	1	1	1	1	1	0	0	0	0	0
2-1	DA91-10317B	"	SR-28/29 OPTION	0	0	0	0	0	1	1	1	1	1
3	DA63-20164B	GUARD-FRE(REF)	GPPS	3	3	3	3	3	3	3	3	3	3
4	DA63-20163B	GUARD-EGG	"	1	1	1	1	1	1	1	1	1	1
	DA63-20170A	GUARD-EGG	"	0	0	0	0	0	1	1	1	1	1
5	DA67-40178A	TRAY-EGG	"	1	1	1	1	1	0	0	0	0	0
6	DA63-20186C	GUARD-VARIETY	"	2	2	2	2	2	1	1	1	1	1
7	DA63-20165C	GUARD-BOTTLE	"	2	2	2	2	2	2	2	2	2	2
8	DA71-70128A	GUIDE-BOTTLE	P.P	1	1	1	1	1	1	1	1	1	1
9	DA71-40133A	STOPPER-DOOR(C)	SCP1 T2.0 ZPC3	1	1	1	1	1	1	1	1	1	1
10	DA71-40116A	STOPPER-DOOR(A)	POM	1	1	1	1	1	1	1	1	1	1
11	6001-000061	SCREW-MACHINE	TH M4X12 STS304	4	4	4	4	4	4	4	4	4	4
12		INLAY-MASCOT	PET	1	1	1	1	1	1	1	1	1	1
13	DA71-40125A	STOPPER-DOOR(B)	SCP1 T2.5 ZPC	1	1	1	1	1	1	1	1	1	1

Indicated part is for electrical safety components

11-4 Cabinet Parts & Unit



NO	CODE-NO	DESCRIPTION	SPECIFICATION	SR-32/33					SR-28/29				
				H	M	L	N	G	H	M	L	N	G
1	DA63-10969B	COVER-HINGE, UP	PP	1	1	1	1	1	1	1	1	1	1
2	DA61-10213A	HINGE, UP	SCP1 T2.5 ZPC3	1	1	1	1	1	1	1	1	1	1
3	DA63-50145A	SHIM-HINGE, UP	RD-PVC	1	1	1	1	1	1	1	1	1	1
4	DA60-10124A	SCREW-TAP, TITE	ZPC2-Y M6X16	4	4	4	4	4	4	4	4	4	4
5	DA61-10213C	SCREW-TAP, TITE	ZPC2-W M6X24	2	2	2	2	2	2	2	2	2	2
6	DA61-10220A	HINGE-MID	SCP1 T4 ZPC2	1	1	1	1	1	1	1	1	1	1
7	DA63-50159A	SHIM-HINGE, MID	RD-PVC T1.0	1	1	1	1	1	1	1	1	1	1
8	DA60-40102A	WASHER	ID8.5 0D16 T1 NY-66	1	1	1	1	1	1	1	1	1	1
9	DA61-70256A	SUPT-FOOT	SHP1 T4.5 ZPC3	2	2	2	2	2	2	2	2	2	2
10	DA60-10124A	SCREW-TAP, TITE	ZPC2-Y M6X16	3	3	3	3	3	3	3	3	3	3
11	DA61-30105A	FOOT-FRONT	PP	2	2	2	2	2	2	2	2	2	2
12	DA61-10150A	HINGE-LOW	SHP1 T4.5 ZPC3	1	1	1	1	1	1	1	1	1	1
13	6001-000034	SCREW-TH	STS M4X15	4	4	4	4	4	4	4	4	4	4
14	DA60-10124A	SCREW-TAP, TITE	ZPC2-Y M6X16	4	4	4	4	4	4	4	4	4	4
15	DA71-60196C	BASE-COMP, ASSY	SBHG1 T1.2	1	1	1	1	1	1	1	1	1	1
16	DA65-20101A	CLAMP-COMP	SK5	4	4	4	4	4	4	4	4	4	4
17	DA63-40004A	GROMMET-COMP	NBR	4	4	4	4	4	4	4	4	4	4
18	SD152P-L1W2	COMPRESSOR	127V/,60Hz	1	1	1	1	1	1	1	1	1	1
	SD162H-L1U2	COMPRESSOR	220V/50~60Hz	1	1	1	1	1	1	1	1	1	1
	SD162Q-L1U2	COMPRESSOR	230~240V/50Hz	1	1	1	1	1	1	1	1	1	1
	SD152C-L1W2	COMPRESSOR	100V/60Hz	1	1	1	1	1	1	1	1	1	1
19	DA34-10003R	O/L-PROTECTOR (115/60)	4TM427PHBYY-53	1	1	1	1	1	1	1	1	1	1
	DA34-10003U	O/L-PROTECTOR (127/60)	4TM317PRHYY-53	1	1	1	1	1	1	1	1	1	1
	DA34-10003A	O/L-PROTECTOR (220/60)	4TM265PRHYY-53	1	1	1	1	1	1	1	1	1	1
	DA34-10003A	O/L-PROTECTOR (240/50)	4TM222PHBYY-53	1	1	1	1	1	1	1	1	1	1
				1	1	1	1	1	1	1	1	1	1
20	DA35-10002C	PTC-RELAY	912X32E100MQ16APE3	1	1	1	1	1	1	1	1	1	1
	DA35-10002D	PTC-RELAY	912X35E330MT20APE2	1	1	1	1	1	1	1	1	1	1
21	DA63-10722A	COVER-RELAY	PP	1	1	1	1	1	1	1	1	1	1
22	DA65-10002A	CLAMP-RELAY, COVER	SK-5	1	1	1	1	1	1	1	1	1	1
23	DA67-40309A	TRAY-DRAIN, WATER	PP	1	1	1	1	1	1	1	1	1	1
24	6002-000213	SCREW-TAP, TH	1-4X12 FE, FZY	2	2	2	2	2	2	2	2	2	2
25	DA67-10430C	CASE-JUNCTION	PP	1	1	1	1	1	1	1	1	1	1
26	6002-000213	SCREW-TAP, TH	1-4X12 FE, FZY	1	1	1	1	1	1	1	1	1	1
27	DA45-10003F	TIMER-DEFROST	100V~127V 6H40M	1	1	1	1	1	1	1	1	1	1
	DA45-10003E	TIMER-DEFROST	220V~240V 6H40M	1	1	1	1	1	1	1	1	1	1

Indicated part is for electrical safety components

NO	CODE-NO	DESCRIPTION	SPECIFICATION	SR-32/33					SR-28/29				
				H	M	L	N	G	H	M	L	N	G
28	6002-000213	SCREW-TAP, TH	1-4X12 FE, FZY	2	2	2	2	2	2	2	2	2	2
29	2501-000413	C-OIL (RUN)	8μF/250VAC	1	1	1	1	1	1	1	1	1	1
	2501-000427	C-OIL (RUN)	3.5μF/350VAC	1	1	1	1	1	1	1	1	1	1
	2501-000422	C-OIL (START)	100μF/125VAC	1	1	1	1	1	1	1	1	1	1
30	DA39-20386C	WIRE-HARNESS RELAY	220V~240V	1	1	1	1	1	1	1	1	1	1
	DA39-20386D	WIRE-HARNESS RELAY	100V~127V	1	1	1	1	1	1	1	1	1	1
31		CBF	BUYER OPTION	1	1	1	1	1	1	1	1	1	1
32	DA34-10122C	SWITCH-DOOR	GRN 2B	1	1	1	1	1	1	1	1	1	1
33	DA63-40237G	GROMMET-DISCHARGE	NBR P16	1	1	1	1	1	1	1	1	1	1
34	DA63-40237H	GROMMET-DISCHARGE	NBR P14	1	1	1	1	1	1	1	1	1	1
35	DA60-41120B	CABLE-TIE	NY66	1	1	1	1	1	1	1	1	1	1
36	6002-000453	SCREW-TAPPING	FH M4X12 STS304	1	1	1	1	1	1	1	1	1	3
37	DA73-30103A	DRYER	CU,OD15.88,L118	1	1	1	1	1	1	1	1	1	1

Indicated part is for electrical safety components

8. Packing dimension





MODEL	A	B	C	D
SR-32/33	664	620	1682	35
SR-28/29	664	620	1557	35

12. How to disassemble of freezing compartment

12-1 COVER-EVAP.ASSY'Y

1) Take out the items in the freezer

2) Dry off the wetness in the handle.



3) Hold the handle with the hand and press the elbow towards the COVER-EVAP, ASSY and press force downwards.





4) While pressing force downwards, pull the handle towards the front at the same time.



Reference : to improve the friction of the handle, use rubber gloves or pick-up tongs.

5) When the COVER-EVAP, ASSY is taken apart, take the necessary corrective measures and this time put them together.





13. How to disassemble of refrigerating compartment

1. Remove the super fresh compartment cover and its shelf.
   - Lift up the cover, pysh the cover (as shown) until the mounting hook (1) disengages, then disengage the other mounting hook (2) and pull out the cover.
   - Pull the shelf forward until it stops, then lift it up and pull it out.



2. Remove the shelves from the fresh food comparment.
   - First remove food from the comparment. With shelf front raised slightly, pull it forward to disengage.



3. Disengage the hooks on the lamp cover of the damper cover.



4. Replace the bulb.
   (Before replacing, check the voltage and current of the bulb. Use rated bulbs only.)